



"Tech Tips"

To Murray Customers Only:

Hose Cold Flow:

While repairing a vehicle... have you ever removed an old hose clamp and seen the deep yet intricate impression left behind in the hose compound. This is called "Compression Set". This impression is now permanent... and given time... it will not rebound to its original appearance.

When you first install a clamp... the new hose material is compressed tightly. Given time... the hose will relax... or not push back as hard against the clamp. This is called "Cold Flow". As the name suggests... the hose compound is actually moving out from underneath the clamp to find a location where there is less applied stress on it. This hose relaxation is usually perceived as a drop in screw installation torque.

A thermal cycle will accelerate the Cold Flow process... and for this reason it is good practice to retighten the clamps after the engine has been warmed up... and cooled back down to room temperature.

For the same reason it is good practice to retighten all clamps while performing periodic maintenance. Eventually the new hose will reach a point of near stability and clamps will go for long periods of time without needing to be retightened.

The newer hose compounds now being used are much better with regard to Cold Flow or relaxation than were hoses used a couple of decades ago. But independent of hose brand, compound, or construction... all hoses will Cold Flow... and eventually take on a Compression Set. To stay safe... tweak those screws periodically.

R. Fay
Chief Engineer



Manufacturer of Automotive, Industrial and Marine Clamp Products

260 Schilling Circle • Hunt Valley, MD, 21031, USA — Ph: 410-771-0380 • Fax: 410-771-5576

www.murraycorp.com • email: sales@murraycorp.com